



***JET Power-Flo***  
**Throttle Body Spacer Installation Instructions**  
**Ford 300 F Series**  
**Part #62128**

1. Remove air intake assembly from the throttle body.
2. Remove the throttle cables and the bolts that mount the throttle linkage to the intake manifold.
3. Remove the 4 bolts that mount the throttle body to the intake manifold.
4. Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.
5. Install the JET Power-Flo throttle body spacer using one gasket between the intake manifold and the spacer and one gasket between the throttle body and the spacer.
6. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.
7. Install the new linkage spacers under the throttle linkage plate. Reinstall and reconnect the linkage assembly and reconnect the cables to the throttle body.
8. Verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. **NOTE:** In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
9. Reinstall the air intake assembly.

**JET PERFORMANCE PRODUCTS**

17491 Apex Circle  
Huntington Beach, CA 92647

**Technical Support: (714) 848-5515**