

JET Power-Flo
Throttle Body Spacer Installation Instructions
2005-2009 Ford Mustang 4.0L
2004-2009 Ford Truck 4.6L
Part #62142

1. **Remove Air Intake Assembly from throttle body.**
2. **Remove the 4 bolts that mount the throttle body to the intake manifold**
3. **Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.**
4. **Install the JET Power-Flo throttle body spacer using one gasket between the intake manifold and the spacer and one gasket between the throttle body and the spacer.**
5. **Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.**
6. **Verify the throttle is NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some applications it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.**
7. **Reinstall the Air Intake assembly.**