



Throttle Body Spacer Installation Instructions

Ford

Part #62166

- 1. Remove the air intake tube from the throttle body and air box.**
- 2. Remove the breather hose and spring clamps connected to the throttle body.**
- 3. Remove the four bolts that mount the throttle body to the intake.**
- 4. Install the JET Power-Flo spacer placing the gasket between the throttle body and the spacer with the supplied longer bolts and washers.**
- 5. Install the longer breather hose and speed clamps supplied in the kit in place of the factory hose and clamps.**
- 6. Reinstall the Intake tube assembly and tighten the hose clamps**

JET Performance Products – 17491 Apex Circle – Huntington Beach, CA 92647

Phone 714-848-5515 Fax 714-847-6290

