



Part Number 69132



Note: Picture may not match your sensor.

### Installation Instructions

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the bolts or clamps that mount the factory Mass Air Flow Sensor to the air intake tube and /or air cleaner assembly.
3. Unplug the wiring connector from the factory Mass Air Flow Sensor.
4. Install the Jet Powr-Flo Mass Air Flow Sensor in the intake tube using the factory screws or clamps that you previously removed. Plug the factory wiring connector into the new sensor.
5. Start the vehicle and verify that the check engine light ***IS NOT ON!***
6. Put your factory sensor away in a safe place. Do not discard your original sensor.

JET Performance Products  
17491 Apex Circle  
Huntington Beach, CA 92647  
Tech:714-848-5515 Fax: 714-847-6290  
[customerservice@powerbyjet.com](mailto:customerservice@powerbyjet.com)  
[www.jetchip.com](http://www.jetchip.com)