



Part Number 69164

Check the JET website for specific Applications
www.jetchip.com



Installation Instructions

1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.
2. Remove the bolts that mount the factory Mass Air Flow Sensor to the air intake tube and /or air cleaner assembly.
3. Unplug the wiring connector from the factory Mass Air Flow Sensor.
4. Install the Jet Powr-Flo Mass Air Flow Sensor in the intake tube using the factory screws that you previously removed. Plug the factory wiring connector into the new sensor.
5. Start the vehicle and verify that the check engine light ***IS NOT ON!***
6. Put your factory sensor away in a safe place. Do not discard your original sensor.

JET Performance Products
17491 Apex Circle
Huntington Beach, CA 92647
Tech:714-848-5515 Fax: 714-847-6290
customerservice@powerbyjet.com
www.jetchip.com