

JET Power-Flo
Throttle Body Spacer Installation Instructions
2005-2006 Toyota Tundra
Part #62148

- 1. Remove Air Intake Assembly from throttle body.**
- 2. Remove the hose clamp that holds the air intake to the throttle body.**
- 3. Remove the nuts and studs that mount the throttle body to the intake manifold.**
- 4. Install the JET Power-Flo throttle body spacer using the supplied gasket between the JET spacer and throttle body.**
- 5. Replace the 4 bolts that mounted the throttle body using the new bolts and flat washers supplied in the kit.**
- 7. Reinstall the air intake to the throttle body.**
- 8. Reinstall and reconnect the vacuum lines and hoses that you removed on the air intake system.**