

JET Power-Flo
Throttle Body Spacer Installation Instructions
General Motors
3.6 L Engines

Part #62165

1. Remove the air intake assembly and from throttle body.
2. Remove the 4 bolts that mount the throttle body to the intake manifold
3. Install the JET Power-Flo throttle body spacer using the new gaskets, placing one gasket on each side of the spacer.
4. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.
5. Verify that the throttle body is securely tightened and that you have reattached any electrical plugs or hardware that you had to remove with the throttle body.
6. Reinstall the Air Intake assembly.