



JET Power-Flo Throttle Body Spacer Installation Instructions Part #62168 2011- up F150 5.0L / 2011- up Mustang 5.0L

1. **DISCONNECT NEGATIVE BATTERY TERMINAL.**
2. **Remove the engine beauty cover.**
3. **Disconnect the breather hose. Remove the air intake tube by loosening the two hose clamps at the throttle body and the air box.**
4. **Remove the four bolts that secure the throttle body to the intake manifold.**
5. **Install the JET Power-Flo throttle body spacer using the supplied gasket. Place the gasket between the JET Power-Flo Spacer and the throttle body.**
6. **Install the four new bolts and washers provided in the kit and tighten the bolts.**
7. **Reinstall the air intake assembly, the breather tube , engine beauty cover and oil cap.**
8. **Reconnect the negative battery cable.**

PARTS LIST:

- (1) **JET Powr-Flo Spacer**
- (1) **Gasket**
- (4) **6m X 70mm Hex Head Bolts**
- (4) **6m Flat Washers**
- (4) **6m lock washers**