



Throttle Body Spacer Installation Instructions 2011-2013 Ford F150 3.5L Eco Boost

Part #62174

1. Remove throttle body air intake assembly from the throttle body.
2. Remove the (4) four factory bolts from the throttle body.
3. Install the JET Power-Flo throttle body spacer using the supplied gasket.
The gasket installs between the spacer and the intake manifold.
4. Replace the four (4) bolts that mount the throttle body to the intake manifold using the four (4) new bolts and four (4) flat washers and four (4) lock washers supplied in the kit.
5. Reinstall the Air Intake assembly.

PARTS LIST:

- (1) JET Power-Flo Spacer
- (1) Gasket
- (4) 6mmx75mm Bolts
- (4) Flat Washers
- (4) Lock Washers

TOOLS NEEDED:

- (1) 8mm Socket
- (1) Ratchet

JET Performance Products – 17491 Apex Circle – Huntington Beach, CA 92647

Phone 714-848-5515 Fax 714-847-6290