



JET Power-Flo

Throttle Body Spacer Installation Instructions

Part #62144

2011- up 3.6L Chrysler, Dodge , Jeep

1. **DISCONNECT NEGATIVE BATTERY TERMINAL.**
 2. **Remove the engine beauty cover from its mounting grommets.**
 3. **Remove the air intake tube by loosening the two hose clamps at the throttle body and the air box. Unplug the IAT sensor in the tube.**
 4. **Remove the four bolts that secure the throttle body to the intake manifold.**
 5. **Install the JET Power-Flo throttle body spacer using the supplied gasket. Place the gasket between the JET Powr-Flo Spacer and the throttle body.**
 6. **Install the four new bolts and washers provided in the kit and tighten the bolts.**
- NOTE: DO NOT OVERTIGHTEN THE BOLTS, YOU CAN STRIP THE PLASTIC MANIFOLD, JUST SNUG THEM DOWN.**
7. **Reinstall the air intake assembly, IAT sensor connector, and engine beauty cover .**
 8. **Reconnect the negative battery cable.**

PARTS LIST:

- (1) JET Powr-Flo Spacer**
- (1) Gasket**
- (4) 6m x 51m Hex Head Bolts**
- (4) 6m Flat Washers**