



JET POWERTECH PULLEYS

90126

INSTRUCTIONS FOR

94 – 03 2.2 CHEVY S-10

1. Remove existing belt(s) and camshaft pulley.
2. Install new pulley. Use Loctite thread loc #242, or equivalent to secure stock bolts.
3. Install gates belt k060733 for 1994 - 97, and gate belt k060721 for 1998 – 03.
4. Ensure adjustment marks on tensioner are within the limit marks.
5. Once bolts are all tightened up, inspect for “pulley wobble” and that the belt is properly seated in pulley(s).